

<b>1. AD-SAM006 SYSTEM OVERVIEW .....</b>	<b>4</b>
<b>1.1. DESCRIPTION .....</b>	<b>4</b>
<b>1.2. SPECIFICATIONS.....</b>	<b>4</b>
<b>1.2.2. RECEIVER.....</b>	<b>4</b>
<b>1.2.3. POWER SUPPLY.....</b>	<b>4</b>
<b>1.3. TABLE: SYSTEM / DETECTION / NOISE .....</b>	<b>5</b>
<b>2 HARDWARE.....</b>	<b>6</b>
<b>2.1. TRANSCEIVER BOARD.....</b>	<b>6</b>
<b>2.2. RX BOARD.....</b>	<b>7</b>
<b>2.3. POWER SUPPLY .....</b>	<b>8</b>
<b>3. QUICK TUNING.....</b>	<b>9</b>
<b>3.1. QUICK INSTALLATION.....</b>	<b>9</b>
<b>3.1.1. PREVIOUS.....</b>	<b>9</b>
<b>3.1.2. SYSTEM INSTALLATION .....</b>	<b>9</b>
<b>3.2. TROUBLESHOOTING .....</b>	<b>9</b>
<b>3.2.1. NO DETECTION .....</b>	<b>9</b>
<b>3.2.2. TOO MUCH DETECTION.....</b>	<b>9</b>
<b>3.2.3. FALSE ALARM.....</b>	<b>9</b>
<b>3.2.4. MAKES OTHER SYSTEMS FALSE ALARM.....</b>	<b>9</b>
<b>3.3. SYNCHRONIZATION PROBLEM.....</b>	<b>10</b>
<b>3.4. NOISE PROBLEM.....</b>	<b>11</b>
<b>3.5. DEAD TRANSMITTER .....</b>	<b>13</b>
<b>3.6. DEAD RECEIVER .....</b>	<b>14</b>
<b>3.7. FALSE ALARM (OR UNKNOWN ALARM) .....</b>	<b>15</b>
<b>4. CONFIGURATION .....</b>	<b>16</b>
<b>4.1. CONNECTION METHOD.....</b>	<b>16</b>
<b>4.1.1. ANTENNA CABLES AND CONNECTION.....</b>	<b>16</b>
<b>4.1.2. POWER SUPPLY CABLE AND CONNECTION .....</b>	<b>17</b>
<b>4.2. CONFIGURATION EXAMPLES .....</b>	<b>18</b>
<b>4.2.1. TRANSCEIVER BOARDS.....</b>	<b>18</b>
<b>4.2.2. RECEIVER BOARDS.....</b>	<b>18</b>
<b>4.2.3. DUAL SYSTEM CONFIGURATION (RX-TX).....</b>	<b>19</b>
<b>4.2.4. SPLIT SYSTEM CONFIGURATION (RX-TX-RX) .....</b>	<b>20</b>
<b>4.2.5. SEVERAL TRANSCEIVER AND RECEIVER ANTENNAS (RX-TX-RX-TX-RX).....</b>	<b>21</b>
<b>4.2.6 TRANSCEIVER TO TRANSCEIVER (TX-TX-TX-TX...).....</b>	<b>22</b>
<b>5. SOFTWARE.....</b>	<b>23</b>
<b>5.1. INSTALLATION PROCEDURE.....</b>	<b>23</b>
<b>5.2. CONNECT .....</b>	<b>24</b>
<b>5.2.1. RS232 PORT .....</b>	<b>24</b>
<b>5.2.2. ANALOG MODEM .....</b>	<b>25</b>
<b>5.2.3. GSM MODEM.....</b>	<b>26</b>
<b>5.2.4. INTERNET MODULE .....</b>	<b>27</b>
<b>5.2.5. HOW TO KNOW THE COM PORT.....</b>	<b>28</b>
<b>5.3. ACCESS .....</b>	<b>29</b>

<b>5.4. MAIN MENU .....</b>	<b>31</b>
<b>5.4.1. SETTINGS.....</b>	<b>31</b>
<b>5.4.2. CONNECT /CONNECTED .....</b>	<b>31</b>
<b>5.4.3. DISCONNECT .....</b>	<b>31</b>
<b>5.4.4. PARAMETERS.....</b>	<b>31</b>
<b>5.4.5. ALARM LIST.....</b>	<b>31</b>
<b>5.4.6. COMMAND TRANSMISSION .....</b>	<b>36</b>
<b>5.4.7. LANGUAGES.....</b>	<b>36</b>
<b>5.4.8. CONFIGURATION.....</b>	<b>37</b>
<b>5.4.9. AUTOTUNING .....</b>	<b>38</b>
<b>5.4.10. REPORT .....</b>	<b>39</b>
<b>5.4.11. UPDATE.....</b>	<b>40</b>
<b>5.4.12. MANUAL .....</b>	<b>40</b>
<b>5.5. SYSTEMS .....</b>	<b>41</b>
<b>5.6. SYSTEM TAB.....</b>	<b>42</b>
<b>5.6.1. STATUS.....</b>	<b>42</b>
<b>5.6.2. SYSTEM TOTALS.....</b>	<b>42</b>
<b>5.6.3. POWER TIMES.....</b>	<b>42</b>
<b>5.6.4. CLOCK.....</b>	<b>43</b>
<b>5.6.5. SAVE ENERGY.....</b>	<b>43</b>
<b>5.6.6. LEDS .....</b>	<b>43</b>
<b>5.6.7. CONFIGURATION OPTIONS.....</b>	<b>43</b>
<b>5.7. TRANSMITTER TAB .....</b>	<b>44</b>
<b>5.7.1. START / STOP TX.....</b>	<b>44</b>
<b>5.7.2. TX LOOPS .....</b>	<b>44</b>
<b>5.7.3. MULTIMONO .....</b>	<b>44</b>
<b>5.7.4. POWER LINE FREQUENCY.....</b>	<b>44</b>
<b>5.7.5. DISCOVERY TOOL.....</b>	<b>45</b>
<b>5.7.6. TRANSCEIVER STATUS .....</b>	<b>48</b>
<b>5.8. RECEIVER TAB .....</b>	<b>49</b>
<b>5.8.1. GAIN.....</b>	<b>49</b>
<b>5.8.2. THRESHOLD .....</b>	<b>49</b>
<b>5.8.3. ANTI NOISE ALGORITHMS.....</b>	<b>50</b>
<b>5.8.4. START/STOP RECEIVER LOOPS.....</b>	<b>50</b>
<b>5.8.5. ANTENNA RESONANCE .....</b>	<b>50</b>
<b>5.8.6. REMOTE RECEIVER .....</b>	<b>50</b>
<b>5.8.7. SIGNAL AND NOISE.....</b>	<b>51</b>
<b>5.9. PEOPLE COUNTER TAB .....</b>	<b>52</b>
<b>5.10. ALARMS TAB.....</b>	<b>53</b>
<b>5.10.1. SOUND OPTIONS .....</b>	<b>53</b>
<b>5.10.2. PAGER OPTIONS .....</b>	<b>53</b>
<b>5.10.3. ALARM TYPES .....</b>	<b>54</b>

## 1. AD-SAM006 SYSTEM OVERVIEW

### 1.1. DESCRIPTION

AD-SAM006 AM systems can detect any 58 kHz resonant circuit or any acousto magnetic tag passing through the detection area.

The system includes Digital Processing System (DPS) in order to achieve great detection range, filtering noise and avoiding possible false alarms.

The tuning is done easily via powerful software. The system can be accessed via laptop and optionally via Internet, Analog MODEM, GSM MODEM, etc....

AD-SAM006 58 kHz systems can have several configurations:

-----  
Mono-antenna:       1 Transceiver pedestal  
Dual System:        2 pedestals (TX-RX)  
Split System:       3 pedestals (RX-TX-RX)  
Any number of TX-RX in line:        n pedestals (RX-TX-RX-TX-RX-TX...)  
Any number of Mono-antennas in line: n pedestals (TX-TX-TX-TX....)  
-----

### 1.2. SPECIFICATIONS

#### 1.2.1. TRANSCEIVE

ELECTRICAL	
<b>Operating Frequency</b>	58 kHz
<b>Transmit Burst Duration</b>	1.5ms
<b>Transmit Burst Repetition Rates</b>	
50Hz 75 or 50 pulses/second (TX burst 1.5ms)	
60Hz 90 or 60 pulses/second (TX burst 1.5ms)	

#### 1.2.2. RECEIVER

ELECTRICAL	
<b>Operating Frequency</b>	58 kHz
<b>Inputs</b>	2

#### 1.2.3. POWER SUPPLY

ELECTRICAL		ENVIROMENTAL	
<b>Primary Input</b>	230Vac / 110Vac	<b>R. Humidity</b>	0 to 85% non condensing
<b>Output #1</b>	12 VAC	<b>Operating Temperature</b>	0° to 50° C
<b>Output #2</b>	20 VAC	<b>Noise level</b>	30dBm
<b>Fuse</b>	500mA Slow / 250V		

### 1.3. TABLE: SYSTEM / DETECTION / NOISE

The system will perform as follows:

DR Label, Gain X5, Threshold 40 (SOLARIS SYSTEM)

<b>LEDS BLINKING</b>	<b>MONO (*)</b>	<b>DUAL</b>
<b>0/1</b>	<b>110 cm</b>	<b>220 cm</b>
<b>1/2</b>	<b>100 cm</b>	<b>200 cm</b>
<b>2/3</b>	<b>85 cm</b>	<b>170 cm</b>


Super pencil ferrite tag, Gain X5, Threshold 40

<b>LEDS BLINKING</b>	<b>MONO (*)</b>	<b>DUAL</b>
<b>0/1</b>	<b>160 cm</b>	<b>350 cm</b>
<b>1/2</b>	<b>150 cm</b>	<b>330 cm</b>
<b>2/3</b>	<b>140 cm</b>	<b>320 cm</b>

For Mono distances are on each side.

## 2 HARDWARE

### 2.1. TRANSCEIVER BOARD




- A: TRANSCEIVER UPPER LOOP
- B: TRANSCEIVER LOWER LOOP
- C: RESONANCE ADJUSTMENT TRANSCEIVER UPPER LOOP
- D: RESONANCE ADJUSTMENT TRANSCEIVER LOWER LOOP
- E: MANUAL TUNING/ADJUSTMENT
- F: VU METER (LED SIGNAL BAR)
- G: POWER CONNECTOR
- H: RELAY
- I: COMMUNICATION
- J: ALARM (LIGHT)
- K: ALARM (BUZZER)
- L: CONNECTION TO THE GREY CONNECTOR ON A RECEIVER BOARD. ALSO RS 485 IN/OUT
- M: CONNECTION TO THE RED/MARKED CONNECTOR ON A RECEIVER BOARD. ALSO RS 485 IN/OUT
- N: SOUND ALARM LEVEL SELECTORS
- O: 485 JUMPER
- P: PEOPLE COUNTER CONNECTOR(TDB.)



### 2.3. POWER SUPPLY

Other Power Supplies on demand to support more than 4 Transceiver Antennas  
All power supply cabling is done with 10 ways flat cable and POLARIZED CONNECTORS.



## 3. QUICK TUNING

### 3.1. QUICK INSTALLATION

#### 3.1.1. PREVIOUS

Always connect the system to clean power lines (No other electrical devices connected)

Always turn on systems ONE by ONE. Once you have tuned the first one, THEN connect the second one, THEN the third, etc....

In order to avoid damaging the electronics, do not place any TURNED OFF antenna near a TURNED ON Transceiver antenna. Please keep the minimum distance, not less than 50cm

**Do not fix the system to the floor** before testing its performance FIRST!

Do not place Receiver and Power line (220Vac/110Vac) cables along the same route.

Please Read this manual BEFORE installing systems!

#### 3.1.2. SYSTEM INSTALLATION

Check cabling / connection needs according to the kind of installation. (See Section 4. [CONFIGURATION](#) ).

Check all the material is ready.

Place the system in the installation area. (DO NOT fix the system to the floor).

Turn the system ON, and connect to the system (Follow Section 5. [SOFTWARE](#))

Check Electrical Noise, Synchro, TX Status, etc.... check everything is normal.

Stabilize external electrical noise to the minimum.

Check Section 1.3. [TABLE: SYSTEM / DETECTION / NOISE](#) to define the maximum detection distance.

If any modifications, save parameters.

Disconnect your laptop and observe the system during some time making several detection tests (buzzer can be disabled to not cause disturbance).

If OK, fix the system to the floor if OK, if not OK, see Section 3.2. [TROUBLESHOOTING](#)

You are done!

### 3.2. TROUBLESHOOTING

#### 3.2.1. NO DETECTION

Try with other tag

Rise Gain (Up to 2-3 LEDS)

Lower Threshold

See Section 3.4. [NOISE PROBLEM](#)

See Section 3.3. [SYNCHRONIZATION PROBLEM](#)

See Section 3.5. [DEAD TRANSMITTER](#)

See Section 3.6. [DEAD RECEIVER](#)

#### 3.2.2. TOO MUCH DETECTION

Lower Gain

Rise Threshold

#### 3.2.3. FALSE ALARM

Look for TAGS near the antennas

See Section 3.7. [FALSE ALARM \(OR UNKNOWN ALARM\)](#)

#### 3.2.4. MAKES OTHER SYSTEMS FALSE ALARM

See Section 3.3. [SYNCHRONIZATION PROBLEM](#)

### 3.3. SYNCHRONIZATION PROBLEM

#### How can I recognize a synchro problem?

Externally: When you turn on your system:

- It makes other 58 kHz systems near alarm
- Your system is showing a high amount of noise in the LED bar (See Section 2. [HARDWARE](#)).
- There is no detection or it is very poor.


Laptop:

- Check Section 5.7.5. [DISCOVERY TOOL](#)

#### How can I know the synchro problem has been solved?

Externally all systems around will be working fine as well as yours.

Laptop: The situation in the discovery mode will be similar to this:



You are done!

### 3.4. NOISE PROBLEM


#### How can I recognize a noise problem?

Externally: When you turn on your system:

- The system shows a high amount of noise in the LED bar.
- The detection might be poor.

Laptop:

- In the scope you will see high amount of noise, in the 4 buffers.



#### How can I solve a noise problem?

Try to locate the source of noise:

- Turn off all electrical equipment in the area. If the noise disappears, start turning all the electrical equipment ONE BY ONE till you get noise again.
- Other way to locate the source of noise is moving the Receiver antenna while at the same time you are looking to the LED bar or the software. See how the orientation of the Receiver antenna affects the amount of noise and you will finally find the source


Then you have to neutralize the source of noise. (It might be related with bad synchro, please check procedure in Section 5.7.5. [DISCOVERY TOOL](#)) Other techniques are:

- Swap Transceiver antenna by Receiver antenna position.
- Ground the noisy device correctly or try to put it as far as possible from the Receiver antenna.
- Use advanced noise techniques 'New Noise fighting algorithms'

### New Noise fighting algorithms

Depending on the level of electrical noise, it is recommended to select different positions in the noise selector. Each antenna is independent.

- Transceiver antenna:
  - There are 2 active modes in noise fighting for Transceiver antenna.
  - Position 0 turns off noise fighting algorithms in Transceiver antenna.
  - Back Ground suppression
- Receiver Antennas:
  - There are 2 active modes in noise fighting for Receiver antennas.
  - Position 0 turns off noise fighting algorithms in Receiver antenna.
  - Back Ground suppression



### How can I know the noise problem has been solved?

Detection will improve. The signs of noise in the LED bar and in the scope will disappear. You are done!

### 3.5. DEAD TRANSMITTER


#### How can I recognize a dead transmitter problem?

Externally: When you turn on your system:

- The system does not detect.

Laptop:

- Voltage near to 0Vpp



#### How can I solve a dead transmitter problem?

If the Transceiver Board is not working, change it by a new one.

Please check the connection cable between the Power Supply and the Transceiver Board.

If the synchro pulse from the POWER supply is not OK, the system will stop the transmission.

If the problem persists, it can be caused by a blown fuse in the Power supply. Change the power supply by a new one.

Check the power line frequency to be 50Hz+/- 1Hz or 60Hz +/- 1Hz.

#### How can I know the dead transmitter problem has been solved?

The system is working normally.

You are done!

### 3.6. DEAD RECEIVER


#### How can I recognize a dead receiver problem?

Externally: When you turn on your system:

- The system does not detect. (Remember that there are 6 independent receivers one for every loop).
- You can try if a dual system to change the receiver cable to red/marked connector or grey connector

Laptop:

- The signal is near 6 dB or less in all receiver buffers.



#### How can I solve a dead receiver problem?

The problem may come from the Transceiver-Receiver connection cable. It may be broken during the installation.

The problem may come from the Receiver Board. It might be damaged. Try another Receiver Board

The problem may come from the Transceiver Board. It may have one Receiver channel damaged. Try another Transceiver Board or test with the other Receiver channel.

#### How can I know the dead receiver problem has been solved?

The system is working normally.

You are done!

### 3.7. FALSE ALARM (OR UNKNOWN ALARM)

#### How can I recognize a false alarms (or unknown alarm) problem?

The system is alarming when not expected to alarm. AD-SAM006 58 kHz systems are very false alarm restrictive.


It is almost impossible that a AD-SAM006 58kHz system is alarming except when:

There is a tag in the detection area

There is another 58 kHz system not in synchro.

#### How can I solve a false alarms (or unknown alarm) problem?

Look for tags near the system. Look in the scope in the software. If you see something similar to this:



Please Stop the TX system. If the alarm disappears, there are at least some LABEL/TAG near.

If not, there might be another 58 kHz system out of synchro affecting our system. Follow procedure in Section 5.7.5. [DISCOVERY TOOL](#)

#### How can I know the false alarms (or unknown alarm) problem has been solved?

The system is working normally, no unexpected alarms.

You are done!

## 4. CONFIGURATION


### 4.1. CONNECTION METHOD

AD-SAM006 58 kHz systems have been designed to fit into every installation needs. They can be configured in multiple ways.

Connection between Transceivers or between Transceivers and Receivers is done through 10 ways telephonic cable which allows easy adaptation to the installation place needs.

#### 4.1.1. ANTENNA CABLES AND CONNECTION

Each Transceiver antenna can be connected to 2 independent Receiver antennas by a 10 ways cable with **NOT polarized connectors**. Please follow the instructions carefully in order to manufacture the cable correctly.




Connect the cable between Antennas following Section 4.2. [CONFIGURATION EXAMPLES](#)  
Test the cable with a system to check that it is working correctly.


You are done!

#### 4.1.2. POWER SUPPLY CABLE AND CONNECTION

Each Transceiver antenna must be supplied by a 7 ways cable with **Polarized connector**.



Connect to POWER SUPPLY




Connect to RX&TX main board

## 4.2. CONFIGURATION EXAMPLES

### 4.2.1. TRANSCIVER BOARDS


The connectors from Transceiver Boards which connect to other antennas are red/marked connector (L in the drawing) and BLACK connector (M in the drawing). Apart from the RX signal, they also take communication in the Transceiver and the 2 local Receiver Boards and communication with further Transceiver Boards in the net, if any. 485 JUMPER (O in the drawing) **must be ON** in the first and last Transceiver Board in the net.



485 JUMPER (O in the drawing) must be OFF in the middle Transceiver Boards in the net.


### 4.2.2. RECEIVER BOARDS

The connectors in the Receiver Board are red/marked connector (F in the drawing) and black connector (G in the drawing).




### 4.2.3. DUAL SYSTEM CONFIGURATION (RX-TX)

For Power Supply Connection, always use a CAB-FL-10-B cable with CON-10-TEL-POL (POLARIZED)




For Power Supply Connection, always use a 7-5 cable with CON-7-5-POL (POLARIZED)




#### 4.2.4. SPLIT SYSTEM CONFIGURATION (RX-TX-RX)

Always connect a CAB-FL-10-I cable with CON-10-TEL-NOPOL (NOT POLARIZED) from RED/MARKED connector of one board to the GREY connector of another board.




For Power Supply Connection, always use a 7-5 cable with CON-7-5-POL (POLARIZED)



#### 4.2.5. SEVERAL TRANSCEIVER AND RECEIVER ANTENNAS (RX-TX-RX-TX-RX)


Always connect a CAB-FL-10-I cable with CON-10-TEL-NOPOL (NOT POLARIZED) from RED/MARKED Connector of one board to the connector of another board.

485 JUMPER must be ON in the first and last Transceiver Board in the net.



**Note:** each board must debug by software, and then connect with CON-10-TEL-NOPOL cable


For Power Supply Connection, always use a 7-5 cable with CON-7-5-POL (POLARIZED)




#### 4.2.6 TRANSCEIVER TO TRANSCEIVER (TX-TX-TX-TX...)

Always connect a CAB-FL-10-I cable with CON-10-TEL-NOPOL (NOT POLARIZED) from RED/MARKED connector of one board to the black connector of another board.

485 JUMPER must be ON in the first and last Transceiver Board in the net.



**Note:** each board must debug by software, and then connect with CON-10-TEL-NOPOL cable  
For Power Supply Connection, always use a 7-5 cable with CON-7-5-POL (POLARIZED)



## **5. SOFTWARE**

The interface of Remote Tuning Software for 58 kHz systems has been designed to allow an easy understanding of all features. Icons are highly intuitive permitting a quick assimilation of concepts.

### **5.1. INSTALLATION PROCEDURE**

Before installation verify that you have Windows98se or higher.

Close all the executing programs.

Run the installer

Select the folder to install the software and click on Install button

## 5.2. CONNECT

### 5.2.1. RS232 PORT


Use an USB to Rs232 adaptor if the computer which will be used to connect to the system does not have a RS232 port.

Connect the communication cable provided to the USB adaptor or directly to the system if the computer has RS232 port.



Run the software and press 'SETTINGS'


1. Select Serial Port Communication.
2. Select Serial Port Comm.
3. Press OK



Press Connect



The software will search for all the systems connected and load them into the System window



## 5.2.2. ANALOG MODEM

Parts needed: Analog Modem MDM58

Connect the communication cable provided from the analog MODEM to the system.


Connect the analog line to the analog MODEM.

Test the MODEM sequence

Run the software and press 'SETTINGS'



1. Select Modem Communication.
2. Select Serial Port Comm.
3. Press OK



Press Connect



The software will search for all the systems connected and load them into the System window



### 5.2.3. GSM MODEM

Parts needed: GSM MODEM.

Input the SIM CARD into the GSM MODEM.

Access the system using Rs232 connection

Using the command PNxxxx, input the PIN number into the system.

SAVE the parameters


Connect the communication cable from the GSM MODEM to the system

At power on, the system will detect that it has a PIN number and will activate the GSM MODEM. Then it will be on hold waiting for the communication to come through.

Run the software and press 'SETTINGS



1. Select Modem Communication.
2. Select Serial Port Comm.
3. Press OK



Press Connect



The software will search for all the systems connected and load them into the System window



## 5.2.4. INTERNET MODULE

Parts needed: Internet Module ACC-TCP/IP


Connect the cable provided to the INTERNET MODULE and to the system.

Connect the ETHERNET/ADSL cable line to the INTERNET MODULE.

Run the software and press 'SETTINGS'




1. Select TCP-IP Communication.
2. Select Client or Server operation.  
For more information See TCP-IP Modules Manual.  
It is possible to save, load or delete the IP/PORT information
3. Press OK



## 5.2.5. HOW TO KNOW THE COM PORT


If you are using a USB to RS232 adapter, check which virtual port is assigned by the adapter. To do this, follow the steps:

- 1. Click on **Start** and then **Control Panel**.
- 2. Click on the Performance and Maintenance link.
- 3. **Note:** If you're viewing the *Classic View* of Control Panel, you won't see this link. Simply double-click on the **System** icon and proceed to Step 4.
- 4. In the *System Properties* window, click on the **Hardware** tab.
- 5. With the *Hardware* tab selected, click on the **Device Manager** button.
- 6. Select Ports (COM & LTP) and check port name used for the adapter.




### 5.3. ACCESS

Double click the SN of the system you want to gain access.



Select Maintenance / Supervisor access  
Input PASSWORD (Factory 12345678 for Maintenance)  
Press OK



The selected system is accessed

The screenshot shows a software interface for system configuration and monitoring. The interface is divided into several sections:

- Top Menu:** Settings, Connected, Parameters, Alarm List, Command Transmission, Languages, Configuration, Autotuning, Disconnect.
- Systems Panel (Left):** Includes a search bar with "SN: F432" and buttons for "Close", "Sound Alarm", "Change ID", and "Change Pass".
- Main Content Area:**
  - Status:** Serial Number: F432, ID: [empty], Model: 0618, Version: 0497.
  - System Totals:**

	Total Alarms	Total Day Alarms	Total Hour Alarms	Total Hour Near Tag Alarm
Antenna Tx	489	63	0	0
Antenna Rx1	1	0	0	
Antenna Rx2	0	0	0	
  - Power On Times:** Power On Times: 46, Power On Hours: 242.
  - Internal Clock:** Date: 11/05/2010, Time: 10:28:32, Update button.
  - Show in Led bar:** Radio buttons for Rx, V1, V2, T1.
  - Save Energy:** From 24 h To 24 h.
- Configuration Options (Right):**
  - Detection:** Enable modification (checkbox), Hard Filter (checkbox checked), Narrow Filter (checkbox), Test 1 (checkbox checked), Test 2 (checkbox), Test 3 (checkbox checked), Test 4 (checkbox checked).
  - Others:** Alive Signal (checkbox checked), Master (checkbox checked), Net (checkbox), Ignore Switches (checkbox).

**Status Bar (Bottom):** Connected, COM1: 19200baud, SN: F432, Master, Net, Power Line Freq: 50Hz, Version 4.97

## 5.4. MAIN MENU




### 5.4.1. SETTINGS




Gain access to the connection settings menu

### 5.4.2. CONNECT /CONNECTED




Connect to the system(s)  
If the connection is active, then it is shown as 'Connected'

### 5.4.3. DISCONNECT



Disconnect from the accessed system

### 5.4.4. PARAMETERS



Reset all parameters in the system to factory values  
Save all parameters  
Refresh all parameters in the software from the system memory


### 5.4.5. ALARM LIST



Displays available alarm list

It is possible to get the data from all the systems on the net by selecting the systems which are required to get historical data from. (Data is refreshed into memory **every hour**)


In this window, it is possible to customize the passages and systems



The Data Mining window will show up as follows:



Select Date ranges:



Select Parameters to display:

**Parameters**

All       None


**Systems**

- Alarms Antenna Tx
- Alarms Antenna Rx1
- Alarms Antenna Rx2
- Near Tag Alarm
- Jammer Alarm
- Power On Times
- Total Alarms

**People Counter**

- Ins Corridor 1
- Ins Corridor 2
- Outs Corridor 1
- Outs Corridor 2
- Total Ins
- Total Outs

Press 'GET LIST' button to get the historical data from the selected systems:



**TABLE DATA**

Data is displayed in a Table with columns as follows:

[-] Main Door

- (SN:08D6 - ID:0001)
- (SN:06A7 - ID:0002)
- (SN:0807 - ID:0003)

Select Date

From: 23/02/2012 To: 29/02/2012

Get List

Parameters

All     None

**Systems**

- Alarms Antenna Tx
- Alarms Antenna Rx1
- Alarms Antenna Rx2
- Near Tag Alarm
- Jammer Alarm
- Power On Times
- Total Alarms

**People Counter**

- Ins Corridor 1
- Ins Corridor 2
- Outs Corridor 1
- Outs Corridor 2
- Total Ins
- Total Outs


Table    Chart    Systems    Period: Day

Period: 23/02/2012 - 29/02/2012

Day	Total Alarms	Total Ins	Total Outs
23/02/12	7	72	79
24/02/12	7	70	80
25/02/12	0	2	2
26/02/12	0	0	0
27/02/12	2	57	55
28/02/12	3	70	77
29/02/12	1	43	33

Export Data    Print Data

Select Period:



- Only by selecting Hour Period, data displayed belongs to one day with periods of 24 hours.

Table Chart Systems Period: Hour Select Day: 23/02/2012 Previous Next

Period: 23/02/2012


Hour	Total Alarms	Total Ins	Total Outs
00	0	0	0
01	0	0	0
02	0	0	0
03	0	0	0
04	0	0	0
05	0	0	0
06	0	0	0
07	0	5	0
08	0	17	10
09	0	4	5
10	0	4	6
11	0	13	8
12	0	13	15
13	0	3	2
14	0	5	12
15	0	1	3
16	7	6	4
17	0	1	2
18	0	0	0
19	0	0	3
20	0	0	0
21	0	0	0
22	0	0	0
23	0	0	0

- Select the day from which you want to get the historical data or click on Previous and Next buttons:


Select Day: 23/02/2012 Previous Next

### CHART DATA

Change to Chart Tab to display the data in graphical style along a horizontal time axis.




Select the style of the chart:




Select perspective



Chart visualization provides for major and minor settings to allow for zooming



Data can be exported into txt file or printed:



## SYSTEMS DATA

Change to Systems Tab to display the data for each system individually.

**TOTAL PERIOD DATA: 23/02/2012 - 29/02/2012**

System Selection	Total Alarms	Total Ins	Total Outs
Main Door	20	314	317
(SN:08D6 - ID:0001)	18	314	317
(SN:06A7 - ID:0002)	2	0	0
(SN:0807 - ID:0003)	0	0	0


**HOURLY DATA MINING: 29/02/2012 13:07:51**

System Selection	Total Alarms	Total Ins	Total Outs
Main Door	0	2	2
(SN:08D6 - ID:0001)	0	2	2
(SN:06A7 - ID:0002)	0	0	0
(SN:0807 - ID:0003)	0	0	0

Total Period Data is the sum of all period data for each system separately.

Hour Data Mining is the sum of the actual hour for each system separately and is refreshed every new hour.

#### 5.4.6. COMMAND TRANSMISSION




Opens Command Transmission window to input any command directly to the system




#### 5.4.7. LANGUAGES



All labels are supported in other languages. You can add new language or delete it.



Add language



Write all the words you need.


	English	Español
Ok	Ok	Ok
Cancel	Cancelar	Ca
Exit	Salir	
Settings	Ajustes	
Select Communication		
Serial Port		
Alarm List		
Select Date		

Save the changes and select the language

#### 5.4.8. CONFIGURATION



The parameters can be saved into a file and then loaded when necessary




## 5.4.9. AUTOTUNING




It is possible to auto tune all the systems in the line automatically

Select the parameters and systems to be tuned and then press “Start Autotuning”



It is possible to name and configure the passages and systems.




## 5.4.10. REPORT



Displays all the system measurements and parameters saved on a file at a certain moment.

Select Save Report into File in order to save all the parameters and measurements from the system:




Click Ok.


Optionally, you can set the following information from the store and the system:

Click Ok and give a name for the Report file

To display a report, select Show Report option, click Ok button and select the report file



The Report will show up as follows:




Information of System, Transceiver, Receiver, People Counter and Alarms will be showed up.

#### 5.4.11. UPDATE




Click on Update Menu to check for new versions available.

#### 5.4.12. MANUAL



Click on Manual Menu to browse this Tuning G10V Manual

## 5.5. SYSTEMS



Options for this section:

- Start a new search to load the systems
- Visualization of systems found with their Serial Number and ID
- Close access or get access to selected system
- Sound the alarm of selected system
- Change ID of selected system (once you gain access)
- Change password (once you gain access)

## 5.6. SYSTEM TAB

The screenshot shows the 'System' tab with the following sections:

- Status:** Serial Number: 08D8, ID: 0001, Model: 1220, Version: 04A7
- System Totals:**

	Total Alarms	Total Day Alarms	Total Hour Alarms	Total Hour Near Tag Alarm
Antenna Tx	1206	1	0	0
Antenna Rx1	50	0	0	0
Antenna Rx2	2721	0	0	0
- Power On Times:** Power On Times: 29, Power On Hours: 9241
- Internal Clock:** Date: 29/02/2012, Time: 13:12:38, Update button
- Show in Led bar:** Radio buttons for RX (selected), V1, V2, T1
- Save Energy:** From: 24 h, To: 24 h
- Configuration Options:**
  - Detection:**
    - Enable modification
    - Hard Filter
    - Narrow Filter
    - Test 1
    - Test 2
    - Test 3
    - Test 4
  - Others:**
    - Alive Signal
    - Master
    - Net
    - Ignore Switches

### 5.6.1. STATUS

The following information can be found: (Only INFO)

- Serial Number
- Current ID
- Model
- Version

**Status**

Serial Number: 08D8, ID: 0001, Model: 1220, Version: 04A7

### 5.6.2. SYSTEM TOTALS

The following information can be found:

- Total Alarms / Total Day Alarms / Total Hour Alarms in Transceiver Antenna
- Total Alarms / Total Day Alarms / Total Hour Alarms in Receiver Antenna RX1
- Antenna RX1: Receiver Board connected on the red/marked connector from the Transceiver Board
- Total Alarms / Total Day Alarms / Total Hour Alarms in Receiver Antenna RX2
- Antenna RX2: Receiver Board connected on the grey connector from the Transceiver Board
- Total Number of Near Tag Alarms

	Total Alarms	Total Day Alarms	Total Hour Alarms	Total Hour Near Tag Alarm
Antenna Tx	1206	1	0	0
Antenna Rx1	50	0	0	0
Antenna Rx2	2721	0	0	0

### 5.6.3. POWER TIMES

The following information can be found:

- Total number of Power ON
- Total Number of Power ON hours (working hours).

**Power On Times**

Power On Times: 29, Power On Hours: 9241

### 5.6.4. CLOCK

Set Date and Time

**Internal Clock**

Date    
Time

### 5.6.5. SAVE ENERGY

The system is automatically turned off during the period selected. If same hour, no action (Always ON)

**Save Energy**

From   h To   h

### 5.6.6. LEDS

This selector is used to choose what information to be displayed on the LED bar (See Section 2.HARDWARE)

**Show in Led bar**

Rx  V1  V2  T1

- RX: The Receiver noise/signal is shown
- V1: The voltage of Transceiver Upper Loop (TX Loop 1) is shown
- V2: The voltage of Transceiver Lower Loop (TX Loop 2) is shown
- T1: Temperature in Transceiver is shown

### 5.6.7. CONFIGURATION OPTIONS

**Configuration Options**

**Detection**

Enable modification

Hard Filter

Narrow Filter

Test 1

Test 2

Test 3

Test 4

**Others**

Alive Signal

Master

Net

Ignore Switches


Detection:

- This should be left as from factory settings.

Others:

- Alive Signal: Activates or deactivates "alive light", which shows that the system is running correctly and it is not "hung"
- Master & NET (ONLY INFO)
- Ignore switches: With this function selected, the system will ignore any change or parameter introduced from the switches. This is to prevent unauthorized access even from the hardware / switches.

## 5.7. TRANSMITTER TAB




### 5.7.1. START / STOP TX



From here the Transmission can be stopped, this can be used to confirm if an alarm is coming from tags / labels.

If the Transmission is stopped and the alarm stops, then the alarm was caused by a tag.

### 5.7.2. TX LOOPS



Turn ON/OFF any of the 2 independent Transceiver loops in the Transceiver antenna. (Default ON).

TX1: Transceiver Upper Loop

TX2: Transceiver Lower Loop

Tx Loops states can be saved.

### 5.7.3. MULTIMONO



This parameter must be ON when connecting multiple transceiver in the same aisle or in a net (Default OFF)


### 5.7.4. POWER LINE FREQUENCY



Information about which is the current power line frequency.

## 5.7.5. DISCOVERY TOOL

Main tool to synchronize the system.



In 99% of cases this adjustment is not necessary. Anyway, it is always good to take a look at the environmental electric noise throughout the “Discovery Mode” feature.

When Discovery Tool is ON, the transmitter is then turned off, and the system ONLY receives. Standard Synchro delay value is 0.2ms



For Slave systems, enable “Follow Master” option in order to have the same synchro than Master. This option is available for systems with version 3.A0 and 4.A0 or higher.




Once the Discovery Tool is ON, electrical noise and other possible systems out of phase are shown on the screen. In the scope is represented the amount of noise in 58 kHz through the 0° phase to the 360° phase in the mains. (From 0 ms to 20 ms in one 50 Hz period).

In the scope, the TX blocks will be represented in the lower side of the yellow line (negative), the TX blocks of other systems out of phase, will be represented in the upper side of the yellow line (positive).


## FIELD SITUATIONS

- In these cases, only the blocks in the lower part can be seen. The presence of another system which is correctly synchronized with yours, can be seen in the break of the first block (RED CIRCLE)





### Systems out of synchro, NEED TO SYNCHRONIZE, Only one external reference


- When another 58 kHz transmitter is transmitting out of synchro, it can be easily seen from the scope screen. The area above the yellow line is reserved for these situations. In the next figure, the presence of another 58 kHz transmitter can be easily seen on that area. Only one external reference means that only 3 TX blocks from other system can be seen in the upper side of the screen.



- Change the delay manually to synchronize with the system out of synchro.



- Match the systems transmissions with one each other...




- As it can be seen on the figure above, our TX blocks (below yellow line) have moved until the position of the other system TX blocks. The synchro can be followed and verified visually. The peaks appearing in the 2 last blocks (RED CIRCLE) are normal when the system is too near.
- After a good synchronization process, you must turn Discovery Mode off, to do so press OFF




**Systems out of synchro, NEED TO SYNCHRONIZE, More than one external reference**

- When there is more than one reference to synchro, then a correct synchronization is not possible. This means that previous to the installation, there were already at least 2 systems out of synchro, probably these systems are already not working. In order to fix the problem it is necessary to previously synchronize between them the existing systems.


- 6 blocks of normal duration, means at least 2 previously not synchronized systems



- 3 blocks of abnormal duration, means at least 2 previously not synchronized systems




- After synchronizing ALL external systems, the situation will be as follows:



- Then the system can be correctly synchronized using this unique and only external reference.
- Please follow step CASE 2, to synchronize de system in accordance.

### 5.7.6. TRANSCIEVER STATUS



#### Transceiver Voltage

- Shows the Voltage in the TX loops. It should be always in the range of 1000 to 1400V (GREEN)
- If it is lower, it might be because a defective transmitter or bad resonance. Then it might be necessary to retune the Transceiver resonance (Hardware).

#### Transceiver Temperature

- Shows the current Temperature in the Transmitter Board.
- Should be always in the green area (10° to 55°).

## 5.8. RECEIVER TAB


Transceiver antenna is also a Receiver antenna, so it has its own receiver side.

Each Transceiver antenna is able to support 2 Receiver antennas.

Selecting 'Transceiver' allows selecting parameters for receiver side of Transceiver antenna


Selecting 'Receiver Rx1' allows selecting parameters for the Receiver Antenna connected on the Transceiver BOARD with red/marked connector.

Selecting 'Receiver Rx2' allows selecting parameters for the Receiver Antenna connected on the Transceiver BOARD with grey connector.



### 5.8.1. GAIN

Gain feature is used to adjust the receiver sensitivity to get the best reception signal.



In order to adjust Gain, simply select the value until you get the required detection.


### 5.8.2. THRESHOLD

Threshold feature is the signal level at which each receiver will trig an alarm.

If you need higher threshold, then increase the Multiplier. A Higher threshold means less sensitive for the system, more quantity of signal will be needed from the tag to trigger an alarm, the detection is reduced.

It is recommended, for maximum sensitivity to keep the Detection Threshold at minimum (40) & Multiplier=1.

In order to adjust Detection Threshold, simply select the value until you get the required detection



### 5.8.3. ANTI NOISE ALGORITHMS

Anti Noise algorithms are used to minimize the electrical noise. Depending on the level of electrical noise, it is recommended to select different positions in the noise selector. Each antenna is independent.

There are 2 active modes in noise fighting.

Position 0 turns off noise fighting algorithms in mono-antenna.

Back Ground suppression is also OFF by default.



### 5.8.4. START/STOP RECEIVER LOOPS

From here, each Receiver loop can be independently turned on and off. If there is a high disturbance in any of them, it can be disabled. Receiver Loops states be saved.



Loop 1 belongs to Upper Loop of the Transceiver Antenna


Loop 2 belongs to Lower Loop of the Transceiver Antenna

### 5.8.5. ANTENNA RESONANCE

Only Receiver Boards.

The Receiver Board controls the resonance of both Receiver loops in the Receiver antenna. The resonance is controlled by the selection of capacitors in this slide in the software. Receiver Antenna resonance might be affected only when installing the system very near metallic frames or metallic doors.

In these cases, Receiver resonance can be modified from the selector.



The factory default value for Receiver Resonance depends on each system (always around 9)

### 5.8.6. REMOTE RECEIVER

Only for Receiver Boards.

Remote Receiver feature is used to allow or not allow the propagation of RX signal to a remote receiver or transceiver antenna, when the systems are split into several aisles.

If ON, it allows propagation of the RX signal in red/marked connector.

If OFF, it does not allow propagation of the RX in red/marked connector.





### 5.8.7. SIGNAL AND NOISE

In the scope area there is a digital oscilloscope display that will help to analyse the noise and signal. Real time electrical noise signals icon will show current electrical signal (Noise and tags if there is any).

There are 4 different reception areas shown on the Signal Bars / Digital Scope: 'Loop 1 Signal' 'Loop 1 Noise', 'Loop 2 Signal' and 'Loop 2 Noise'.

Loop 1 belongs to Upper Loop of the Transceiver / Receiver Antenna

Loop 2 belongs to Lower Loop of the Transceiver / Receiver Antenna





#### □ SITUATION 1 (When there is no tag near)

The reception areas shown on the Signal Bars / Digital Scope should look as follows:

In the 4 different reception Bars/Areas, only electrical noise in the environment is shown, as there is no tag near.

All 4 reception Bars/Areas MUST HAVE SIMILAR values.




#### □ SITUATION 2 (When there is a tag near)

The reception areas shown on the Signal Bars / Digital Scope should look as follows:

In the 4 different reception Bars/Areas, the 2 reception Bars/Areas reserved for noise keep the same as in SITUATION 1 BUT the 2 Bars/Areas reserved for tag signal, show higher values than the ones reserved for noise.

This way, an alarm caused by tags can be easily identified.



**5.9. PEOPLE COUNTER TAB**

TBD.

## 5.10. ALARMS TAB

This section allows you to configure the different alarms patterns in the system.

The screenshot shows the 'Alarms' tab in a software interface. On the left is a tree view with categories: Detection (Tag Alarm, Jammer Alarm, Near Tag Alarm, Bad Synchronization), People Counter (Ins, Outs, People Counter locked). The 'Tag Alarm' is selected. The main area is titled 'Tag Alarm' and has a 'Sound' icon. It contains several dropdown menus: 'Times to Sound' (8), 'Off Time' (0.1 s), 'First Beep Time' (0.3 s), 'Evens Beep Time' (0.3 s), 'Odds Beep Time' (0.3 s), and 'Time Rele On (on alarm)' (0.4 s). A 'Test Sound' button is on the right. Below this is a 'Message to display on Beeper' section with two text input fields for 'LCD Line 1' and 'LCD Line 2', each with a '( 11 Characters)' label, and a 'Send' button.

### 5.10.1. SOUND OPTIONS

Select number of times to sound and customize beep duration time.

This panel shows the 'Sound' configuration options. It includes five dropdown menus: 'Times to Sound' (3), 'Off Time' (0.3 s), 'First Beep Time' (0.5 s), 'Evens Beep Time' (0.5 s), and 'Odds Beep Time' (0.1 s). A 'Test Sound' button with a speaker icon is located on the right side of the panel.

### 5.10.2. PAGER OPTIONS

Type the messages to display on Pager in order to receive a message when an alarm event occurs.  
Click on the icon to enable or disable

This panel is titled 'Message to display on Pager' and features a pager icon and a checkbox. It contains two text input fields for 'LCD Line 1' and 'LCD Line 2', each with a '( 11 Characters)' label. A 'Send' button with a right-pointing arrow is on the right.

### 5.10.3. ALARM TYPES

#### Tag Alarm

Standard alarm for a 58 kHz tag. Click on the icon to enable or disable.

Relay

- When an alarm occurs, the alarm closes a relay and triggers anything connected to it.
- RELAY SPECIFICATIONS: 240V & 250mA.
- Normal Open(NO) & Normal Close(NC) contacts

Time Relay On (On Alarm)  s

Light Options

- Select the number of flashes. This feature is available for each antenna.

Antenna Tx	Antenna Rx1	Antenna Rx2
Times <input type="text" value="8"/>	Times <input type="text" value="8"/>	Times <input type="text" value="8"/>
Off Time <input type="text" value="0.2"/>	Off Time <input type="text" value="0.2"/>	Off Time <input type="text" value="0.2"/>
On Time <input type="text" value="0.2"/>	On Time <input type="text" value="0.2"/>	On Time <input type="text" value="0.2"/>

#### Jammer Alarm

This alarm occurs when system finds an inhibitor of 58 kHz

Click on the icon to enable or disable.

Select threshold level when activating this alarm (>7 recommended).

Threshold  Sensitivity (Maximum: 1 / Minimum: 15)

#### Near Tag Alarm

This alarm occurs when a 58kHz label/tag is located near the antennas

Disable by default. Click on the icon to enable or disable.

#### Power Synchro Signal Failure

Synchro Signal: It is used to synchronize transmission blocks with zero crossing power line.

The signal comes out from the Power Supply and goes to the Transceiver Board Supply.

Enabled by default. When Power Synchro Signal fails, system would not run properly and alarm event occurs.

#### Ins

This alarm occurs on entrance people detection

Disable by default. Click on the icon to enable or disable.

#### Outs

This alarm occurs on exit people detection

Disable by default. Click on the icon to enable or disable.

#### Blocked People Counter

This alarm occurs when IR-TX Module has been blocked during 1 minute at least.

Disable by default. Click on the icon to enable or disable.